



BEVEL UNITS

RANGE Z


SOLID SHAFTS
C/Y/J/F

HOLLOW KEYWAYED SHAFTS
B/W/H/E

HOLLOW SPLINED SHAFTS
N/L/P/K

HOLLOW KEYWAYED SHAFTS
+ FLANGE
A/V/G/D

HOLLOW SPLINED SHAFTS
+ FLANGE
R/S/M/T



FIXING FACES (R-S-T-U-X-Z)

MOUNTING POSITIONS (K-L-M-N-P)

OKR	OKS	OKT	OKU	OKX	OKZ
OLR	OLS	OLT	OLU	OLX	OLZ
OMR	OMS	OMT	OMU	OMX	OMZ
ONR	ONS	ONT	ONU	ONX	ONZ
OPR	OPS	OPT	OPU	OPX	OPZ



BEVEL UNITS RANGE Z


SOLID SHAFTS
C/V/J/F

HOLLOW KEYWAYED SHAFTS
B/W/H/E

HOLLOW SPLINED SHAFTS
N/L/P/K

HOLLOW KEYWAYED SHAFTS
+ FLANGE
A/V/G/D

HOLLOW SPLINED SHAFTS
+ FLANGE
R/S/M/T



FIXING FACES (R-S-T-U-X-Z)

MOUNTING POSITIONS (K-L-M-N-P)	<p>IKR</p>	<p>IKS</p>	<p>IKT</p>	<p>IKU</p>	<p>IKX</p>	<p>IKZ</p>
	<p>ILR</p>	<p>ILS</p>	<p>ILT</p>	<p>ILU</p>	<p>ILX</p>	<p>ILZ</p>
	<p>IMR</p>	<p>IMS</p>	<p>IMT</p>	<p>IMU</p>	<p>IMX</p>	<p>IMZ</p>
	<p>INR</p>	<p>INS</p>	<p>INT</p>	<p>INU</p>	<p>INX</p>	<p>INZ</p>
	<p>IPR</p>	<p>IPS</p>	<p>IPT</p>	<p>IPU</p>	<p>IPX</p>	<p>IPZ</p>